



11625 Prosperous Drive
Odessa, FL 33556
877-584-5847

PBC26-4 Installation Information

Strip Length 1"

Port	Wire Range	Torque (in-lbs)
#2 Main	#2 - #6	50
#4 Tap	#4 - #14	35

1. Attach Bonding Connector to wall. (Screws not provided)
2. Insert grounding electrode conductor into the main lay-in portion of connector.
3. Torque screw for grounding electrode conductor to torque value listed above.
4. Insert bonding/grounding conductor(s) from communication equipment into each of the four taps provided.
5. Torque screw for communication grounding conductor to torque value listed above.
6. Install cover with screw provided

Quality

*

Service

*

Experience

*

Value

info@polarisconnectors.com

www.polarisconnectors.com